

Gefen Remote Hex Codes

All codes on the following pages are for use with CHANNEL 1, the default channel that ships on all Gefen remotes. For remote channel configuration, please see the documentation that came with your specific product. To use the codes in this document, simply refer to the section that corresponds with the Gefen remote model that came with your product. There are many commercial universal remote manufacturers that will accept Pronto hex codes for use with their products. Contact your universal remote manufacturer for compatibility with these codes. Please feel free to contact technical support if you are having issues with the following codes.

RMT-16IR

Remote Button	HEX Code
1	0000 0067 0000 000A 0045 0045 0045 0045 0045 0045 0022 0022 0045 0022 0022 0022 0022 0022 0022 0022 0022 0022 0022 0BF5
2	0000 0067 0000 000A 0045 0045 0045 0045 0045 0045 0022 0022 0045 0022 0022 0022 0022 0022 0022 0022 0022 0022 0045 0022 0BF5
3	0000 0067 0000 000A 0045 0022 0022 0022 0022 0045 0045 0045 0022 0022 0045 0022 0022 0022 0022 0022 0022 0045 0045 0BF5
4	0000 0067 0000 000A 0044 0044 0044 0044 0044 0044 0022 0022 0044 0022 0022 0022 0022 0022 0022 0044 0022 0022 0022 0BF5
5	0000 0067 0000 000A 0045 0022 0022 0022 0022 0045 0045 0045 0022 0022 0045 0022 0022 0022 0022 0045 0045 0022 0022 0BF5
6	0000 0067 0000 000A 0044 0022 0022 0022 0022 0044 0044 0044 0022 0022 0044 0022 0022 0022 0022 0044 0044 0044 0022 0BF5
7	0000 0067 0000 000A 0044 0022 0022 0022 0022 0044 0044 0044 0022 0022 0044 0022 0022 0022 0022 0044 0022 0022 0044 0BF5
8	0000 0067 0000 000A 0044 0044 0044 0044 0044 0044 0022 0022 0044 0022 0022 0022 0022 0044 0022 0022 0022 0022 0022 0BF5
9	0000 0067 0000 000A 0045 0022 0022 0022 0022 0045 0045 0045 0022 0022 0045 0022 0022 0045 0045 0022 0022 0022 0022 0BF5
10	0000 0067 0000 000A 0045 0022 0022 0022 0022 0045 0045 0045 0022 0022 0045 0022 0022 0045 0045 0022 0022 0045 0022 0BF5
11	0000 0067 0000 000A 0045 0022 0022 0022 0022 0045 0045 0045 0022 0022 0022 0022 0022 0022 0045 0022 0022 0045 0045 0BF5
12	0000 0067 0000 000A 0045 0045 0045 0045 0045 0045 0022 0022 0022 0022 0022 0022 0045 0022 0022 0045 0022 0022 0022 0BF5
13	0000 0067 0000 000A 0045 0022 0022 0022 0022 0045 0045 0045 0022 0022 0022 0022 0022 0022 0045 0045 0045 0022 0022 0BF5
14	0000 0067 0000 000A 0045 0022 0022 0022 0022 0045 0045 0045 0022 0022 0022 0022 0022 0022 0045 0045 0045 0045 0022 0BF5
15	0000 0067 0000 000A 0045 0022 0022 0022 0022 0045 0045 0045 0022 0022 0022 0022 0022 0022 0045 0045 0022 0022 0045 0BF5
16	0000 0067 0000 000A 0045 0045 0045 0045 0045 0045 0022 0022 0022 0022 0022 0022 0045 0045 0022 0022 0022 0022 0022 0BF5

Gefen Remote Pronto Hex Codes

RMT-2IR

Remote Button	HEX Code
1	0000 0067 0000 000A 0045 0045 0045 0045 0045 0045 0022 0022 0045 0022 0022 0022 0022 0022 0022 0022 0022 0022 0022 0BF5
2	0000 0067 0000 000A 0045 0045 0045 0045 0045 0045 0022 0022 0045 0022 0022 0022 0022 0022 0022 0022 0022 0045 0022 0BF5

RMT-3IR

Remote Button	HEX Code
1	0000 0067 0000 000A 0044 0044 0044 0044 0044 0044 0022 0022 0044 0022 0022 0022 0022 0022 0022 0044 0022 0022 0022 0BF5
2	0000 0067 0000 000A 0044 0022 0022 0022 0022 0044 0044 0044 0022 0022 0044 0022 0022 0022 0022 0044 0044 0044 0022 0BF5
3	0000 0067 0000 000A 0044 0044 0044 0044 0044 0044 0022 0022 0044 0022 0022 0022 0022 0044 0022 0022 0022 0022 0022 0BF5

RMT-4IR

Remote Button	HEX Code
1	0000 0067 0000 000A 0045 0045 0045 0045 0045 0045 0022 0022 0045 0022 0022 0022 0022 0022 0022 0022 0022 0022 0022 0BF5
2	0000 0067 0000 000A 0045 0045 0045 0045 0045 0045 0022 0022 0045 0022 0022 0022 0022 0022 0022 0022 0022 0045 0022 0BF5
3	0000 0067 0000 000A 0045 0022 0022 0022 0022 0045 0045 0045 0022 0022 0045 0022 0022 0022 0022 0022 0022 0045 0045 0BF5
4	0000 0067 0000 000A 0044 0044 0044 0044 0044 0044 0022 0022 0044 0022 0022 0022 0022 0022 0022 0044 0022 0022 0022 0BF5

RMT-6IR

Remote Button	HEX Code
1	0000 0067 0000 000A 0044 0044 0044 0044 0044 0044 0022 0022 0044 0022 0022 0022 0022 0022 0022 0044 0022 0022 0022 0BF5
2	0000 0067 0000 000A 0045 0022 0022 0022 0022 0045 0045 0045 0022 0022 0045 0022 0022 0022 0022 0045 0045 0022 0022 0BF5
3	0000 0067 0000 000A 0044 0022 0022 0022 0022 0044 0044 0044 0022 0022 0044 0022 0022 0022 0022 0044 0044 0044 0022 0BF5
4	0000 0067 0000 000A 0045 0022 0022 0022 0022 0045 0045 0045 0022 0022 0045 0022 0022 0045 0045 0022 0022 0045 0022 0BF5
5	0000 0067 0000 000A 0045 0022 0022 0022 0022 0045 0045 0045 0022 0022 0022 0022 0022 0022 0045 0022 0022 0045 0045 0BF5
6	0000 0067 0000 000A 0045 0045 0045 0045 0045 0045 0022 0022 0022 0022 0022 0022 0045 0022 0022 0045 0022 0022 0022 0BF5

Gefen Remote Hex Codes

RMT-8IR

Remote Button	HEX Code
1	0000 0067 0000 000A 0044 0044 0044 0044 0044 0044 0022 0022 0044 0022 0022 0022 0022 0022 0022 0044 0022 0022 0022 0BF5
2	0000 0067 0000 000A 0045 0022 0022 0022 0022 0045 0045 0045 0022 0022 0045 0022 0022 0022 0022 0045 0045 0022 0022 0BF5
3	0000 0067 0000 000A 0044 0022 0022 0022 0022 0044 0044 0044 0022 0022 0044 0022 0022 0022 0022 0044 0044 0044 0022 0BF5
4	0000 0067 0000 000A 0044 0022 0022 0022 0022 0044 0044 0044 0022 0022 0044 0022 0022 0022 0022 0044 0022 0022 0044 0BF5
5	0000 0067 0000 000A 0044 0044 0044 0044 0044 0044 0022 0022 0044 0022 0022 0022 0022 0044 0022 0022 0022 0022 0022 0BF5
6	0000 0067 0000 000A 0045 0022 0022 0022 0022 0045 0045 0045 0022 0022 0045 0022 0022 0045 0045 0022 0022 0022 0022 0BF5
7	0000 0067 0000 000A 0045 0022 0022 0022 0022 0045 0045 0045 0022 0022 0045 0022 0022 0045 0045 0022 0022 0045 0022 0BF5
8	0000 0067 0000 000A 0045 0045 0045 0045 0045 0045 0022 0022 0022 0022 0022 0022 0045 0022 0022 0045 0022 0022 0022 0BF5

RMT-SR-IR

Remote Button	HEX Code
Input	0000 0067 0000 000A 0045 0045 0045 0045 0045 0045 0022 0022 0045 0022 0022 0022 0022 0022 0022 0022 0022 0022 0022 0BF5
Component 1	0000 0067 0000 000A 0045 0045 0045 0045 0045 0045 0022 0022 0045 0022 0022 0022 0022 0022 0022 0022 0022 0045 0022 0BF5
Power	0000 0067 0000 000A 0045 0022 0022 0022 0022 0045 0045 0045 0022 0022 0045 0022 0022 0022 0022 0022 0022 0045 0045 0BF5
Output	0000 0067 0000 000A 0044 0044 0044 0044 0044 0044 0022 0022 0044 0022 0022 0022 0022 0022 0022 0044 0022 0022 0022 0BF5
Component 2	0000 0067 0000 000A 0045 0022 0022 0022 0022 0045 0045 0045 0022 0022 0045 0022 0022 0022 0022 0045 0045 0022 0022 0BF5
HDMI 1	0000 0067 0000 000A 0044 0022 0022 0022 0022 0044 0044 0044 0022 0022 0044 0022 0022 0022 0022 0044 0044 0044 0022 0BF5
Exit	0000 0067 0000 000A 0044 0022 0022 0022 0022 0044 0044 0044 0022 0022 0044 0022 0022 0022 0022 0044 0022 0022 0044 0BF5
Up	0000 0067 0000 000A 0044 0044 0044 0044 0044 0044 0022 0022 0044 0022 0022 0022 0022 0044 0022 0022 0022 0022 0022 0BF5
Menu	0000 0067 0000 000A 0045 0022 0022 0022 0022 0045 0045 0045 0022 0022 0045 0022 0022 0045 0045 0022 0022 0022 0022 0BF5

Gefen Remote Hex Codes

RMT-SR-IR Continued

Remote Button	HEX Code
Left	0000 0067 0000 000A 0045 0022 0022 0022 0022 0045 0045 0045 0022 0022 0045 0022 0022 0045 0045 0022 0022 0045 0022 0BF5
OK	0000 0067 0000 000A 0045 0022 0022 0022 0022 0045 0045 0045 0022 0022 0022 0022 0022 0045 0022 0022 0045 0045 0BF5
Right	0000 0067 0000 000A 0045 0045 0045 0045 0045 0045 0022 0022 0022 0022 0022 0022 0045 0022 0022 0045 0022 0022 0022 0BF5
Reset	0000 0067 0000 000A 0045 0022 0022 0022 0022 0045 0045 0045 0022 0022 0022 0022 0022 0045 0045 0045 0022 0022 0BF5
Down	0000 0067 0000 000A 0045 0022 0022 0022 0022 0045 0045 0045 0022 0022 0022 0022 0022 0045 0045 0045 0045 0022 0BF5
Auto	0000 0067 0000 000A 0045 0022 0022 0022 0022 0045 0045 0045 0022 0022 0022 0022 0022 0045 0045 0022 0022 0045 0BF5
HDMI 2	0000 0067 0000 000A 0045 0045 0045 0045 0045 0045 0022 0022 0022 0022 0022 0022 0045 0045 0022 0022 0022 0022 0022 0BF5

RMT-8HDS-IR

Remote Button	HEX Code
Up	0000 0067 0000 000A 0045 0045 0045 0045 0045 0045 0022 0022 0045 0022 0022 0022 0022 0022 0022 0022 0022 0022 0022 0BF5
Left	0000 0067 0000 000A 0045 0045 0045 0045 0045 0045 0022 0022 0045 0022 0022 0022 0022 0022 0022 0022 0022 0045 0022 0BF5
Enter	0000 0067 0000 000A 0045 0022 0022 0022 0022 0045 0045 0045 0022 0022 0045 0022 0022 0022 0022 0022 0022 0045 0045 0BF5
Right	0000 0067 0000 000A 0044 0044 0044 0044 0044 0044 0022 0022 0044 0022 0022 0022 0022 0022 0022 0044 0022 0022 0022 0BF5
Down	0000 0067 0000 000A 0045 0022 0022 0022 0022 0045 0045 0045 0022 0022 0045 0022 0022 0022 0022 0045 0045 0022 0022 0BF5
Menu	0000 0067 0000 000A 0044 0022 0022 0022 0022 0044 0044 0044 0022 0022 0044 0022 0022 0022 0022 0044 0044 0044 0022 0BF5
Source	0000 0067 0000 000A 0044 0022 0022 0022 0022 0044 0044 0044 0022 0022 0044 0022 0022 0022 0022 0044 0022 0022 0044 0BF5
Output	0000 0067 0000 000A 0044 0044 0044 0044 0044 0044 0022 0022 0044 0022 0022 0022 0022 0044 0022 0022 0022 0022 0022 0BF5