



CAT5 • 7000HD
USER MANUAL

www.gefen.com

ASKING FOR ASSISTANCE

Technical Support:

Telephone (818) 772-9100
(800) 545-6900

Fax (818) 772-9120

Technical Support Hours:

8:00 AM to 5:00 PM Monday thru Friday.

Write To:

Gefen Inc.
C/O Customer Service
20600 Nordhoff Street
Chatsworth, CA 91311

www.gefen.com
support@gefen.com

Notice

Gefen Inc. reserves the right to make changes in the hardware, packaging and any accompanying documentation without prior written notice.

CAT5•7000HD is a trademark of Gefen Inc.

TABLE OF CONTENTS

- 1** Introduction and Operation Notes
- 2** How it Works
- 3** CAT5•7000HD Front Panel Descriptions
- 4** CAT5•7000HDS Back Panel Layout
- 5** CAT5•7000HDS Back Panel Functions
- 6** CAT5•7000HDR Back Panel Layout
- 7** CAT5•7000HDR Back Panel Functions
- 8** CAT5•7000HD - Wiring Diagram
- 9** CAT5 Link Cable Wiring Diagram
- 10** Service Switch Usage Guide
- 11** Frequently Asked Questions
- 12** Terminology
- 13** System Specifications
- 14** Warranty

INTRODUCTION

Thank you for purchasing the new ex•tend•it CAT5•7000HD series by Gefen, Inc.

The ex•tend•it CAT5•7000HD by Gefen allows users the benefits of extending USB, audio in, audio out, PS/2, RS232, and video signals beyond the desktop. In a growing number of applications, broadcast stations and production facilities there is a need to locate a computer remotely, from the keyboard, mouse, and video monitor. A CPU may need to be shared between several users or moved to another room because of annoying fan noise.

The CAT5•7000HD series can be used to extend computers with noisy fans, printers, hard drives, scanners, cameras, keyboards, mouse, and any other USB-type peripherals. The CAT5•7000HD has the potential to cover the distance of 150 feet over industry standard Category 5 (CAT-5) cables. One can connect additional CAT5•7000HD series to the same computer, allowing access to the same computer from other locations up to 150 feet apart.

OPERATION NOTES

READ THESE NOTES BEFORE INSTALLING OR OPERATING THE CAT5•7000HD SYSTEM

- Industry standard Category-5 (CAT-5) cables are used to operate CAT5•7000HD systems.
- The CAT5•7000HD units are housed in a metal box for better RF shielding.

* CAT6 cable is suitable for high resolutions at 50 meters.

HOW IT WORKS

CONTENTS

The CAT5•7000HD system consists of:

- (1) CAT5•7000HDS (sender unit)
- (1) CAT5•7000HDR (receiver unit)
- (2) 5 VDC power supply
- (2) DVI to HDMI cables (6FT)
- (1) USB cable (6FT)
- (2) PS/2 cables (6FT)
- (1) Audio cable (6FT)
- (1) User Manual

HOW IT WORKS

In its most basic application, the CAT5•7000HDS sender unit resides next to the computer. Supplied with the system, DVI cables, PS/2 keyboard, PS/2 mouse, audio, and USB cables, they connect the computer to the CAT5•7000HDS sender unit.

The CAT5•7000HDR receiver unit is placed next to the monitors, keyboard, mouse, and USB peripherals at the remote location. The monitor and keyboard are connected to the CAT5•7000HDR, similar to the way they are connected to the back of the computer (PC or Macintosh).

CAT5•7000HDS FRONT PANEL DESCRIPTIONS



|
1

Front Panel Function Descriptions

- 1 **Power On Indication** - Indicates that the unit is on and plugged in.

CAT5•7000HDR FRONT PANEL LAYOUT




|
1

Front Panel Function Descriptions

- 1 **POWER ON INDICATOR** - Indicates that the unit is on and plugged in.


CAT5•7000HDS BACK PANEL LAYOUT



CAT5•7000HDS BACK PANEL LAYOUT

- 1 **POWER** - 5 VDC external power supply
- 2 **HDMI IN 1** - HDMI Input connects to your computer with the supplied DVI to HDMI cable
- 3 **CAT5 Video 1** - RJ-45 input extends HDMI input 1 with CAT-5 cable
- 4 **CAT5 USB/DDC1** - RJ-45 input extends USB and DDC1 signals with CAT-5 cable
- 5 **HDMI IN 2** - HDMI Input connects to your computer with the supplied DVI to HDMI cable
- 6 **CAT5 Video 2** - RJ-45 input extends HDMI input 2 with CAT-5 cable
- 7 **CAT5 USB/DDC2** - RJ-45 input extends USB and DDC2 signals with CAT-5 cable
- 8 **USB IN** - USB Input from computer
- 9 **KEYBOARD** - PS/2 keyboard input from computer
- 10 **MOUSE** - PS/2 mouse input from computer
- 11 **AUDIO** - RJ-45 input extends audio in and audio out 2
- 12 **SERIAL PS/2** - RJ-45 input extends RS-232 and PS/2 signals
- 13 **RS232 IN** - RS232 input from computer
- 14 **AUDIO OUT 2** - Audio mini jack input connects to computers microphone input
- 15 **AUDIO IN** - Audio mini jack input connects to computers audio output (Audio 2 offers improved signal to noise ratio by using differential signal technics)


CAT5-7000HDR BACK PANEL LAYOUT



CAT5•7000HDR BACK PANEL FUNCTIONS

- 1 **POWER** - 5 VDC external power supply
- 2 **CAT5 USB/DDC1** - RJ-45 input extends USB and DDC1 signals with CAT-5 cable
- 3 **CAT5 Video 1** - RJ-45 input extends video input 1 with CAT-5 cable
- 4 **DVI OUT 1** - DVI output connects to the monitor 1 for local video
- 5 **CAT5 USB/DDC1** - RJ-45 input extends USB and DDC1 signals with CAT-5 cable
- 6 **CAT5 Video 2** - RJ-45 input extends video input 2 with CAT-5 cable
- 7 **DVI OUT 2** - DVI output connects to the monitor 2 for local video
- 8 **USB OUT** - USB Output to Devices
- 9 **KEYBOARD** - PS/2 mini din connects to PS/2 keyboard
- 10 **MOUSE** - PS/2 mini din connects to PS/2 mouse
- 11 **AUDIO** - RJ-45 input connects CAT-5 cable to receive extended audio in and audio out 2 signals
- 12 **SERIAL PS/2** - RJ-45 input connects CAT-5 cable to receive extended RS-232 and PS/2 signals
- 13 **RS232** - DB-9 connector connects to RS-232 devices
- 14 **AUDIO IN** - Audio mini jack connector connects to microphone
- 15 **AUDIO OUT 2** - Audio mini jack connects to speakers

CAT5•7000HD WIRING DIAGRAM



RJ-45 Jack



White/Orange

Orange

White/Green

Blue

White/Blue

Green

White/Brown

Brown

RJ-45 Jack



1

2

3


4

5

6

7

8



SERVICE SWITCH USAGE GUIDE

Gefen CAT5 DVI Extenders (sender and receiver) both contain a pair of service switches located on the board inside the case. These service switches are used to select from a set of configurations that will equalize the signal to best match the conditions in your setup. For the CAT5 7000HD, there is one bank per monitor in both the sender and receiver.

Sender Service Switches

Option No.	Switch 1 Position	Switch 2 Position	Description
1	0 (OFF)	0 (OFF)	Strong Line Driver (Default)
2	1 (ON)	0 (OFF)	Weak Line Driver

Receiver Service Switches

Option No.	Switch 1 Position	Switch 2 Position	Description
1	0 (OFF)	0 (OFF)	EQ 0 (Default)
2	1 (ON)	0 (OFF)	EQ 1
3	0 (OFF)	1 (ON)	EQ 2
4	1 (ON)	1 (ON)	EQ 3

Adjustment Guidelines:

- 1) Higher EQ level is used to equalize poor/low quality CAT-5e cables
- 2) Stronger Line Driver is used to boost signals through longer cables
- 3) It is an optimal balance of Line Driver and EQ that will result in the best possible picture.

TROUBLESHOOTING

Frequently Asked Questions

What kind of CAT-5e cable should I be using?

Solid core CAT-5e cable rated at 350 Mhz, terminated in 568a or 568b is the minimum requirement. CAT-6 cables are also a viable cable to use. Higher resolutions and transmission lengths greater than 80 feet might require low skew cables for optimum performance.

Why does the CAT5 sender unit have a HDMI connector on the input?

A HDMI connector was used on the input to optimize space on the board by using the smaller connector. HDMI is electrically equivalent to DVI-D.

I'm getting no video on the screens, what can I check?

First thing to check is make sure that the video CAT5 is linked to the other video CAT5 port and the same with the DDC ports. Test to make sure the units are working with short CAT-5e cables 15-20 feet. Units shipped starting 12-2005 have the service switches inside the unit enabled. Please refer to the Service Switch Usage Guide on page 10.

I'm getting no video on the screens using ADC to DVI adapters, what is wrong?

ADC to DVI adapters remove the necessary 5V line that the extenders require on the input to operate. To enable the 5V you will need to open up the sender unit. Next to each DVI/HDMI input connector will be a jumper that needs to be shorted to enable 5V to the input. This should only be enabled when using a ADC to DVI Adapter otherwise damage to your video card may result.

How can I fix the flickering picture?

Flickering or a Blinking image is the result of a loss of sync between the display and the source. Try lowering the resolution to see if that helps, if it does, the CAT-5 cables you are using are unable to handle the bandwidth of the higher resolution and thus you are losing sync. Try a shielded CAT-5e cable on the Video to reduce interference. You can also try adjusting the service switches. Usually this is caused from either too much or too little of a boost. Please refer to the service switch guide on page 9 for the different combinations.

Why is there a green or pink tint to my picture?

A tint of green or pink in the picture is a result of incorrect colorspace being transmitted. This can be resolved by recycling power on your devices including the extender. If this does not help, the DDC data containing the colorspace is not being transmitted correctly due to loss in the CAT5 cable, try replacing the DDC cable.

I can't seem to get my RS-232 devices to detect and connect, what's wrong?

The CAT5-9000HD system only extends the Tx and Rx lines of RS232. If you need full RS232 extension of every line, you will need the standalone RS232 Extender units.

Can I run the CAT-5 cable through a patch bay?

No, the signal will not transmit reliably

TERMINOLOGY

CAT-5

Category 5 cable, commonly known as Cat 5, is an unshielded twisted pair type cable designed for high signal integrity. The actual standard defines specific electrical properties of the wire, but it is most commonly known as being rated for its Ethernet capability of 100 Mbit/s. Its specific standard designation is EIA/TIA-568. Cat 5 cable typically has three twists per inch of each twisted pair of 24 gauge copper wires within the cable.

CAT-5e

Similar to Cat 5 cable, but is enhanced to support speeds of up to 1000 megabits per second

DDC

Short form for Display Data Channel. It is a VESA standard for communication between a monitor and a video adapter. Using DDC, a monitor can inform the video card about its properties, such as maximum resolution and color depth. The video card can then use this information to ensure that the user is presented with valid options for configuring the display

DDWG

Digital Display Working Group DDWG are the creators of the DVI specification.

DVI

Digital Visual Interface. Connection standard developed by Intel for connecting computers to digital monitors such as flat panels and DLP projectors. A consumer electronics version, not necessarily compatible with the PC version, is used as a connection standard for HDTV tuners and displays. Transmits an uncompressed digital signal to the display. The latter version uses HDCP copy protection to prevent unauthorized copying

USB

Universal Serial Bus. An external peripheral interface standard for communication between a computer and external peripherals over a cable using bi-serial transmission.

VESA

Video Electronic Standards Association, a consortium of manufacturers formed to establish and maintain industry wide standards for video cards and monitors. VESA was instrumental in the introduction of the Super VGA and Extended VGA video graphics standards with a refresh rate of 70 Hz, minimizing flicker and helping to reduce user eyestrain and fatigue.

PS/2

A port type developed by IBM for the purpose of connecting a keyboard or mouse to a PC. The PS/2 port has a mini DIN plug containing 6 pins. PS/2 ports are used so that the serial port can be used by another device. The PS/2 port is often called the mouse port.

RS-232

Recommended Standard 232. This is the de facto standard for communication through PC serial ports. It can refer to cables and ports that support the RS232 standard.

SPECIFICATIONS

Video Amplifier Bandwidth	1.65 GHz
Single Link Range	1920 x 1200
Vertical Frequency Range	50-60 Hz
DVI Output Connector Type	DVI-D
HDMI Input Connector Type	HDMI
Link Connector	RJ-45
USB - "A" Connector	USB Out
USB - "B" Connector	USB Device Input
PS/2 Keyboard Connectors	8 Pin MiniDin
PS/2 Mouse Connectors	8 Pin MiniDin
RS232 Connector	DB-9
Power Consumption	15 Watts (max.)
Power Supply	5 VDC (External)
Dimensions	8.44"W x 2"H x 4.5"D
Shipping Weight	7Lbs

WARRANTY

Gefen Inc. warrants the equipment it manufactures to be free from defects in material and workmanship.

If equipment fails because of such defects and Gefen Inc. is notified within two (2) year from the date of shipment, Gefen Inc. will, at its option, repair or replace the equipment, provided that the equipment has not been subjected to mechanical, electrical, or other abuse or modifications.

Equipment that fails under conditions other than those covered will be repaired at the current price of parts and labor in effect at the time of repair. Such repairs are warranted for ninety (90) days from the day of reshipment to the Buyer.

This warranty is in lieu of all other warranties expressed or implied, including without limitation, any implied warranty or merchantability or fitness for any particular purpose, all of which are expressly disclaimed.

1. Proof of sale may be required in order to claim warranty.
2. Customers outside the US are responsible for shipping charges to and from Gefen.
3. Copper cables are limited to a 30 day warranty and cable must be free from any scratches, markings, and neatly coiled.

The information in this manual has been carefully checked and is believed to be accurate. However, Gefen Inc. assumes no responsibility for any inaccuracies that may be contained in this manual. In no event will Gefen Inc., be liable for direct, indirect, special, incidental, or consequential damages resulting from any defect or omission in this manual, even if advised of the possibility of such damages. The technical information contained herein regarding CAT5•7000HD features and specifications is subject to change without notice.